

4530 & 4030 L- SEALERS		
COMPONENTS ON SEAL ARM ASSEMBLY		part #
SEAL ARM (HEAD) ASSEMBLY COMPLETE	MTB	10-36235-19
4030 SEAL ARM (HEAD) ASSY REPLACE W/ 4530 head above		
4530 SEAL WIRE (six pack of wires)	SIDE	10-41690-04
4530 SEAL WIRE (six pack of wires)	FRONT	10-41690-17
4030 SEAL WIRE (six pack of wires)	SIDE	10-41690-04
4030 SEAL WIRE (six pack of wires)	FRONT	10-41690-05
NUT, BRASS FOR ANCHOR SCREW		545-24-20-30
SCREW, BRASS (seal wire anchor bolt mounted in tensioner)		524-24-71-30
GROUND STRAP (copper "C" plate at corner)		10-41686
BLOCK, GROUNDING (right side of anchor point of front seal wire)		10-36224
BLOCK, INSULATOR (front of side wire)		10-16047
BLOCK, INSULATOR (in wire tensioner)		10-41327
BLOCK, LIFTER FOR SEAL WIRE		10-36210
RTV CEMENT (attaches transite strip)		573-10-02-01
SCREW, ATTACHES FRONT SEAL WIRE AT CORNER		521-12-02-01
SEAL WIRE CONNECTOR KIT		10-16201
SHAFT FOR CAM AND MOUNTING SPRING		10-16051
TENSIONER ASSY W/CAM, STUDS, SPRINGS, MOUNT (side)		10-41212
TENSIONER ASSY W/CAM, STUDS, SPRINGS, MOUNT (front)		10-41211
THUMB NUT, BLACK PLASTIC (attaches seal wire)		568-03-03
TRANSITE INSULATOR 40" LENGTHS (under seal wires)		10-16041-18
WASHER, BRASS (under thumb nut & screw above)		548-24-19
CAM FOR TENSIONER FRONT		10-16264
CAM FOR TENSIONER SIDE		10-16048
BEARINGS, seal head pivot bearings		560-70-06
BOLTS, adjusters for mag/seal wire microswitches		527-65-40-01
HANDLE FOR CAM		10-16049
SPRING FOR TENSIONERS		562-70-17
THREADED ROD-holds microswitch adjusts bolts		MTB 10-36227-02
FILM HOLDDOWNS		part #
FILM HOLDDOWN, COMPLETE FRONT 4530		10-41104-14
FILM HOLDDOWN, COMPLETE FRONT 4030		10-41104-07
FILM HOLDDOWN, COMPLETE SIDE ALL		10-41104-06
SHOULDER BOLTS FOR HOLDDOWNS		10-16449
SPRING FOR HOLDDOWNS		562-72-47
HB-3		part #
COVER, BOTTOM METAL SHEILD FOR RECEPTICLE		10-41326
COVER, TOP METAL BRACKET SUPPOSRTS RECEPTICLE		10-16148
EXTENSION ARM, BURNER SLIDES IN THIS RACK		10-41258
GLOW TIP FOR HB-3 STANDARD TIP		10-41265-20
GLOW TIP LARGER "S" TIP		10-41265-25
HOLEBURNER COMPLETE		HB-3
HOLEBURNER RECEPTICLE (on seal arm)		600-11-02
O-RING, HEIGHT ADJUSTER		573-40-13

POST, HEXAGON MOUNTING POST	10-41252
THUMBWHEEL, BLACK PLASTIC KNOB ON HB-3	568-20-19
CLOSER (DOOR) ASSEMBLY COUNTER WEIGHT	part #
CLOSER ASSEMBLY MTB	10-40168
COUNTER WEIGHT SUPPORT ROD, (HOOKS)	10-40094
COUNTER WEIGHT MTB	10-36419-04
SEAL PAD ASSEMBLY COMPONENTS	part #
4030 SEAL PAD COMPLETE W/ HOLDER, PAD, TAPE front	10-41410-02
4030 SEAL PAD COMPLETE W/ HOLDER, PAD, TAPE side	10-41410-01
4530 SEAL PAD COMPLETE W/ HOLDER,PAD, TAPE front	10-50575-07
4530 SEAL PAD COMPLETE W/ HOLDER,PAD, TAPE side	10-50575-08
SEAL PAD 1" FOAM 36" LENGTH	10-50588-05
SEAL PAD 3/4" FOAM 36" LENGTH	10-16058-16
TEFLON SLEEVE MATERIAL 12" X 9 YARDS	573-56-64
TEFLON TAPE 2 1/2" 9 YARD ROLL	573-56-68
TEFLON TAPE 3/4" 10 YARD ROLL	573-56-69
TEFLON TAPE 3/4" 36 YARD ROLL	573-56-17-01
MAGNET ASSEMBLY COMPONENTS	part #
BOLT, MOUNTS SPRING AND PLATE TO BRACKET	531-66-73-01
BRACKET, CONTACT PLATE MOUNTING	10-50835
CONTACT PLATE (MOUNTED TO SEAL HEAD)	10-50834
MAGNET	640-40-06
MTG BLOCK, MAGNET HOLDER BACKUP PLATE	10-36418
MTG PLATE, MAGNET HOLDER	10-41340
NUY, NYLOCK	546-57-34
SPRING, ON CONTACT PLATE	562-72-66
WASHER	548-50-05
CONVEYOR ASS'BY COMPONENTS MB MODELS	part #
ADJUSTER BOLT FOR TENSIONER ASSEMBLY	527-65-40-01
ANCHOR NUT FOR ADJUSTER	10-36181
BRUSHES- FOR CONVEYOR MOTOR	640-45-11
BELT,CONVEYOR W/ LACING & CONNECTOR ROD	10-36231-06
CRANK HANDLE	10-16591-02
DRIVE ROLLER	10-36460-02
DRIVE ROLLER BEARING	560-15-09
DRIVE ROLLER SPROCKET	562-22-07
IDLER ROLLER	10-36459-02
LAG TAPE FOR DRIVE ROLLER	10-16788
LIFT ROD, (on scissor jack replace with lift screw)	10-41175
LIFT SCREW (threaded rod for crank handle)	10-36203-05
LIFT SCREW BUSHING, BRASS	10-36229
LIFT SCREW COLLAR	557-07-09
LIFT SCREW THRUST BEARING	560-30-52
NOTE: SHADED POLE MOTOR NEEDS MOTOR,BRACKET AND PLATE	
MOTOR	615-40-11
MOTOR BRACKET	10-41310

MOTOR PLATE	10-41309
MOTOR SPROCKET	562-22-06
TIMING BELT	562-32-01
ELECTRICAL COMPONENTS	
	part #
SWITCH, SEAL, MAGNET, CONVEYOR MICROSWITCH	610-18-22
BRUSHES, MOTOR	640-45-11
CAPACITOR, MAGNETS 2.2 micro 16volts	632-21-22-52-06
CAPACITOR, MAGNETS 20 micro 250wvolts	632-24-20-63-25
CIRCUIT BREAKER, CONVEYOR	610-70-33
CIRCUIT BREAKER, MAIN POWER	610-70-10
CONTROLLER, BELT SPEED	10-54342
LIGHTS, INDICATOR 120 VOLT	625-60-31
LIGHTS, INDICATOR 220 VOLT	625-60-30
MAGNET	640-40-06
MAIN POWER CORD	10-40172-30
MOTOR, CONVEYOR	615-40-11
SWITCH, ON/OFF	610-14-09
RECTIFIER, MAGNETS	635-70-29
RELAY CONTACTOR	610-50-04
TERMINAL JUMPER	600-54-01
TERMINAL STRIP 16 PIN DRAWER	600-50-44
TERMINAL STRIP 4 PIN RECTIFIER	600-50-06
TERMINAL STRIP 9 PIN UPPER DECK	600-50-10
TIMER KNOB (ROUND)	568-03-23
TIMER, CONVEYOR AND MAGNETS (EM UP DWELL)	10-54180-91
TRANSFORMER, (seal wire)	640-10-48-01
TRANSFORMER, HOLEBURNER	640-10-35
TRANSFORMER, SEAL WIRES	640-10-37
SEAL WIRE TEMP & BALANCE COMPONENTS	
	part #
BALAST WIRE TEMP EQUALIZER JUMPER 4030 10"	10-40198-05
BALAST WIRE TEMP EQUALIZER JUMPER 4530 15"	10-40198-06
CONTACT SWITCH, ADJUSTING DIAL ON FRONT PANEL	610-18-23
KNOB FOR CONTACT SWITCH	568-30-02
MONITOR WIRE	10-16457
TEMP CONTROL ASSEMBLY, " K TIMER " " MONITOR "	10-16450
FILM CRADLE/SEPERATOR TRAY COMPONENTS	
	part #
BRACKET, OPENING ROD MOUNT	10-50551
BRAKE THUMBSCREW	540-43-32
COLLAR, FILM POSITIONING	10-36466
COLLAR, ROLLER MOUNTING RETAINER	557-07-09
FILM BRAKE	10-50554
FILM OPENING ROD	10-41386
FRONT PLATE	10-36389
MOUNTING BRACKET	10-16441
REAR PLATE	10-36390-01
ROLLER, FILM CRADLE	10-36458-02
SEPERATOR TRAY STAINLESS STEEL	10-40180
THUMBSCREW FOR OPENING ROD POSITION	568-20-05